

Wet Sounds Stealth Sound Bar ROPS Installation

- Please note: Your Wet Sounds Stealth Bar comes with hardware, that may not all be needed in this application. You may find extra hardware in your Battle Armor ROPS hardware package, as well, to make up for a shortage in some Wet Sound kits.
- 1) Remove Wet Sounds sound bar from package along with the hardware. Below is the hardware you will need to use from the Wet Sounds kit. 2 spacers, 2 T-nuts, (4)-8mm hex nuts and (4)-8mm lock nuts.



- 2) Slide T-bolts into undercuts of sound bar.



- 3) Install spacer onto T-bolts and secure T-bolts into place using (1)-8mm lock washer and (1)-8mm hex nut, per T-bolt. Lock into place approximating 12" apart.



- 4) Mount the plates to the ROPS, using the provided 5/16" U-bolts and 5/16" Locking Flange Nuts, thru the slotted holes. Make sure the round holes are spaced at 12" to accommodate the T-bolt spacing from step 3. NOTE: T-bolt mounting holes should be towards the rear of the mower, i.e. the backside of the ROPS.



- 5) The Wet Sounds Stealth bar is now ready to mount to the ROPS Plates. Secure with (2)-8mm lock washers and (2)-8mm hexnuts.



- 6) You are now ready to follow the instructions provided with the Wet Sounds Stealth Sound Bar for wiring and operation. Battle Armor recommends securing the cables to the ROPS with the included cable ties.

