

## Can-Am Defender Rear Bumper Installation



- 1) Remove Battle Armor Rear Bumper and hardware from box. Hardware supplied is shown below.

Contains the following: (4)- 5/16" x 2 1/2" hex bolts, (8) 5/16" flat washers, and (4) 5/16"-18 Nylon insert locknut.



- 2) With a 5/16" drill bit and using the underside frame holes as guides. Drill 4 holes through the bed.



3) Raise the bumper into location and attach using the supplied hardware.



4) Note the bumper will swing with the bed so oversized tires may limit how far bed will dump.